



Channels with VinoSeal clamping flange-

After carefully unloading, identify the channel lengths and position them in correct sequence adjacent to the floor rebate into which they are to be installed.

1. If necessary, bolt sections together using the gaskets and bolts provided. Tighten bolts from bottom centre working outwards, one left, one right, to equalise the pressure on the gasket.
2. Fit the "o" ring seal to the channel outlet spigot
3. Lift channel into floor rebate and connect to gully. Using the levelling bolts provided, adjust channel height to finish floor level.
4. Bed levelling bolts with stiff-mix concrete and check the top of the channel has remained level.
5. Place and level channel as previously described and bolt down expansion frame.
6. Backfill to Vinoseal sub frame.
7. Remove clamping strips. Dress vinyl over sub frame.
8. Replacing clamping strips, screw down, trim Vinyl.
9. Clean and protect as previously described.