



VINOSEAL DRAINAGE CHANNEL INSTALLATION

Series 3510/6051

After carefully unloading, identify the channel lengths and position them in correct sequence adjacent to the floor rebate into which they are to be installed.

1. If necessary, bolt sections together using the gaskets and bolts provided. Tighten bolts from bottom centre working outwards, one left, one right to equalise the pressure on the gasket.
2. Fit the "O" ring seal to the channel outlet spigot.
3. Lift channel into floor rebate and connect to gully. Using the levelling bolts provided, adjust the channel height to finish floor level.
4. Bed levelling bolts with stiff-mix concrete and check the top of the channel has remained the same.
5. Backfill flush with Vinoseal-sub frame.
6. Remove clamping strips and dress the vinyl sheet flooring over the sub-frame.
7. Replace the clamping strips, screw down, trim vinyl.
8. Allow concrete to cure.
9. For deep channels, plug outlet and fill with water to ensure channels do not float while concrete cures.
10. Identify temporary brace bars (*15/15 angle tack welded in position along channel at nom. 500mm centres*) and after ensuring surrounding concrete has cured, twist or grind out. **DO NOT HAMMER OUT.**
11. Channel may also include permanent brace bars – these can be clearly identified as 4mm thick bars at no. 1,200mm centres spanning the width of the channel and being positioned vertically in channel shoulder- these are to be left.
12. Locate relevant gratings for the channel and place in position.
13. Remove debris from channel, and plastic protective tape from channel shoulder, then clean with soapy water.
14. Flush Channel.

ENSURE THE SYSTEM IS ADEQUATELY PROTECTED FROM POSSIBLE DAMAGE RESULTING FROM THE CONTINUATION OF BUILDING WORK IN THIS AREA.

Telephone: 01952 588488 **Facsimile:** 01952 684395 **Address:** Halesfield 10, Telford, TF7 4QP, UK.
Email: sales@componentdevelopments.com **Website:** www.componentdevelopments.com

Accreditations: ISO 9001:2008 Quality Assurance ISO 14001:2004 Environmental Management OHSAS 18001:2007 Occupational Health & Safety

Component Developments is a division of Webster-Wilkinson Ltd. Our standard Terms and Conditions apply.
Company Registration Number: 892102 VAT Registration Number: 159 2898 12